



PUSH-BUTTON BOLTS				
CODE	F	L	S	X
D00350.20.XX	20	202	16	18
D00350.25.XX	20	252	16	18
D00350.30.XX	20	302	16	18
D00350.40.XX	20	402	16	18